

STICK

SK 075H..EWS

SK 071H..EWS

SK 070H..

SK 075H..


SK 071H..

SK 071H..120

SK 130H..

SK 135H..

SK 131H..



1


Montaggio Assembly




$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX




OK

2

a




b



c

 CALDO
HOT

 FREDDO
COLD




075EWS
071EWS
071 070 075
131 130 135



075EWS
070 075
130 135

d

075EWS
071EWS
071 070 075
131 130 135





CH9



075EWS
070 075
130 135



e





F

Funzionamento
Working





075 EWS
071 EWS






M

Manutenzione
Service





S Sostituzione Cartuccia
How to replace Cartridge

075EWS
071EWS
071 070 075
131 130 135



Sostituzione Aeratore 075EWS
How to replace Aerator 071EWS

071 070 075
131 130 135



c Sostituzione Snodo
How to replace Joint

131 130 135